
## AC-I **Wiring Diagram and Installation Notes**



## **IMPORTANT INSTALLATION NOTES**

- 1. 40 and 50 amp breakers are rated to a maximum of 120 VAC line-to-neutral or 240 VAC line-to-line. They are not rated for 240 VAC line-to-neutral systems.
- 2. The maximum current capacity of the installed bus bar is 50 amps. Also, a 50 amp double-pole master breaker must be installed if total loads at any given time may exceed 30 amps.
- 3. See the reverse of this sheet for important information regarding panel wiring to conform to USCG regulations and ABYC standards.

D02000035A As of July 2001



E-Mail: sales@newmarpower.com

**EURO WAREHOUSE** P.O. Box 1306, Newport Beach, CA 92663 ELECTRONIC POWER PRODUCTS Phone:+31-35-603-2494 Fax:+31-35-603-2149 E-Mail: sales@newmarpower.com

www.newmarpower.com